



USB
Amanaero Combo384

OPT

PLR135
/T110

SW1

1
2
3
4
5
6
7
8

DC IN
+24V

COAX
IN

RC
-vout
-vin
COM
+vin
+vout

USB

VOL

I2SP12

I2SP11

INSEL

OPT
COAX

LED

USB

R6

I2C
SCL
SDA
GND

EM-DAC 4497SHP

EM Audio
EMI SUKE

LCH

GND

OUT

RCH

GND

OUT

HP

LCH

GND

RCH

LED
-R
-I
-B

POW

ON

OFF

SW3

RC

-vin

+vin

-vout

COM

+vout