

EM-WORD OUT2 ver1.0 1/2
EMISUKE AUDIO
2011/05

出力周波数選択

SW(HEX)	WORD OUT
0 (0000)	44.1K
1 (0001)	48.0K
2 (0010)	50.0K
3 (0011)	88.2K
4 (0100)	96.0K
5 (0101)	100.0K
6 (0110)	176.4K
7 (0111)	192.0K
8 (1000)	200.0K
9 (1001)	OFF

0 : オープン
 1 : GNDショート

OSC周波数選択

JP1-1	
OFF	OSC=10M
ON	OSC=24.576M

LCD表示

JP1-2	
OFF	OutA/OutB
ON	OutC/OutD

